

ReadyNAS 6.4 新機能概要説明

ReadyNAS 6.4.0 において追加された新しい機能について概要を説明します。


- 共有に対する **Quota** 機能（使用可能な容量を制限する機能）
対象は共有のみであり、ユーザー単位に行うことはできません。
設定は共有作成時および共有の設定画面から可能です。

datastore

The screenshot shows the configuration interface for a datastore named 'datastore'. The 'Properties' tab is selected. The 'Name' field contains 'datastore'. The 'Description' field is empty. There are checkboxes for 'Bit Rot Protection (Copy-on-write)' and 'Compression', both of which are unchecked. The 'Snapshot Schedule' is set to 'Never'. There is an unchecked checkbox for 'Allow Snapshot Access'. The 'Folder' field is empty. The 'Size' section is highlighted with a red box and shows 'Size: Quota 750 GB'. At the bottom, there are three buttons: 'OK', 'Cancel', and 'Apply'.

2. ReadyCLOUD で共有可能なウェブリンクの生成

ダウンロード時にパスワードの付与、およびリンククリック時に通知設定可能
共有単位での共有可能なウェブリンクの生成も可能



Create Web Link for File(s)

WINRE_DRV_VOL-b001.spf

Requires password

YTAxMzZiNjVm

Expires After: number of downloads 5

Notify me when link is clicked

Cancel

Create

Create Web Link for File(s)

WINRE_DRV_VOL-b001.spf

https://readycloud.netgear.com/client/dllink.html#t=13etesthh49p8sf/WINRE_DRV_VOL-b001.spf

Select the above link and copy it by holding the CTRL+C keys

Close

3. 簡易ヘルプの追加


The screenshot shows the NETGEAR ReadyNAS Admin Page. At the top, there is a navigation bar with tabs for System, Shares, iSCSI, Accounts, Network, Apps, Cloud, Backup, Admin Password, and Language. Below this is a secondary navigation bar with icons for Overview, Volumes, Performance, Settings, Logs, Power, and Refresh. A red box highlights a question mark icon in the top right corner. Another red box highlights a 'ReadyNAS Help' pop-up window that is open over the 'Volumes' section. The help window has a title bar 'ReadyNAS Help' and a close button. The main content of the help window is titled 'Basic Volume and RAID Concepts' and contains the following text: 'To get the most out of your ReadyNAS storage system, it is helpful to understand the basics of volumes and RAID. Understanding these concepts is the first step to making good decisions about how to configure, manage, and use your ReadyNAS storage system.' Below this text are two numbered links: '1. [Volumes](#)' and '2. [RAID](#)'. At the bottom of the help window, it says 'Parent topic: [Volume Configuration](#)' and 'Next topic: [Manage Volumes](#)'. In the background, the 'data' volume is visible with a status of 'RAID 0' and statistics: Data: 35.14 MB, Snapshots: 0, Free: 2.71 TB.

4. ボリューム全体におけるスナップショットの占める割合の表示 (共有タブおよびシステム>ボリューム)


This screenshot shows a portion of the navigation bar with tabs for System, Shares, iSCSI, and Accounts. The 'Shares' tab is currently selected and highlighted in blue.

This screenshot shows the details for the 'data' volume. At the top, there is a dropdown arrow and the label 'data'. Below this is a horizontal bar chart representing storage usage. The bar is mostly white, indicating free space, with a small blue segment representing data and a small yellow segment representing snapshots. Below the bar, it says '2.41 TB free of 2.71 TB'. To the left of the bar are three colored squares with labels: a blue square for 'Data', a yellow square for 'Snapshots', and a white square for 'Free'. To the right of the bar is a tooltip box with the following information: 'Data: 125.09 GB', 'Snapshots: 184.26 GB', and 'Free: 2.41 TB'. Below the tooltip is a blue folder icon labeled 'Home Folders'.

- ボリュームスケジュールの位置変更 (元 : [システム]>[設定]>[ボリュームスケジュール]→[システム]>[ボリューム]>ギアマークをクリック>[ボリュームスケジュール])



- [管理者パスワード]を管理画面トップに移動



7. 警告でのメール通知先を複数設定可能に変更 ([システム]>[設定]>[警告])

▼ Alerts

Alert Contacts   

contact1@netgear.com
contact2@netgear.com
contact3@netgear.com

Email Options

Automatic

Email Account Provider: Custom 

User: joebloggs

Password:

Advanced Options: ▲

Send Test Message