



arlo™

Arlo Quadpod Mount  
Quick Start Guide



## What's Included



Quadpod mount



Security screw



Washer



Window decal

## Mount Your Arlo Camera

1. Use the security screw to fasten your Arlo Pro or Arlo Go camera to the quadpod mount.



If you are using Arlo Pro or Arlo Go camera with a skin, place the washer between the screw and the quadpod mount when securing the camera to the mount.



2. Bend the legs until the mount is in a stable position that supports the camera.



For more information about positioning your camera, see the user manual, which is available online at [support/arlo.com](https://support.arlo.com).

# You're Done!

To view useful tutorial videos, find troubleshooting tips, or get support, visit [support.arlo.com](https://support.arlo.com).

©NETGEAR, Inc., NETGEAR, the NETGEAR Logo, and Arlo are trademarks of NETGEAR, Inc. Any non-NETGEAR trademarks are used for reference purposes only.

## Compliance

For the current EU Declaration of Conformity, visit [http://kb.netgear.com/app/answers/detail/a\\_id/11621/](http://kb.netgear.com/app/answers/detail/a_id/11621/).

For regulatory compliance information, visit <http://www.netgear.com/about/regulatory/>.

**NETGEAR®**

350 East Plumeria Drive  
San Jose, CA 95134, USA



**NETGEAR INTL LTD**

Building 3, University Technology Centre  
Curraheen Road, Cork, Ireland



January 2017

201-21379-01